



DIAGONAL CORNER TOE KICK ASSEMBLY INSTRUCTIONS

- 1) FIRST PLACE BOTH SECTIONS DOWN AS SHOWN, WITH TRIANGULAR CORNER BRACE BLOCKS AT TOP.
- 2) THE BACK SUPPORT OF THE TWO SECTIONS IS PLACED AGAINST THE BACK OF THE CABINET, AS FAR INTO THE REAR CORNER AS POSSIBLE.
- 3) THE FIRST SUPPORT OF THE TWO SECTIONS IS PLACED TO THE FRONT OF THE CABINET SO THAT THERE IS 3 ½" FROM THE FRONT OF THE FACE FRAME TO THE FACE OF THE FRONT SUPPORT.